

Connector Kit Thermocouple Connectors with Shield

Product Overview

The new IRt/c miniature low noise connectors are designed to provide an easy connection of ground wires to IRt/c's and extension wire. The drain wire of a 20 AWG twisted shield cable or the shield of the overbraided wire is crimped and held in place by the internal hardware. They have excellent thermal and electrical characteristics to assure high accuracy. Each connector includes a write-on insert and an external ground strap to maintain the electrical connection of the ground wire and strengthen the mechanical connection between connectors.



- Easy Installation of IRt/c, with up to 1000' (300 m) Extension Cable
- Connector Ground Protects Against Electrical Noise Errors
- Write-On Area for Easy Identification
- Superior Mechanical Connection Prevents Signal Loss due to Vibration or Wire Movement
- Rugged Glass-Filled Nylon Shell Rated to 425°F (218°C)
- High Purity Thermocouple Alloy Pins and Sockets
- Available in J, K, E, T Types

